

富知源刷钻机配件图册 FZY-SZ

FZY RHINESTONE TRANSFER PAPER MACHINE PARTS LIST

序号	零件名称	NAME	PARTS NUMBER	REMARK
1	开关电源	24 V SMPS	PARTS NO.001	
2	主板	MAIN BOARD	PARTS NO.002	
3	调速器	SPEED CONTROLLER	PARTS NO.003	
4	接近开关	SENSOR	PARTS NO.004	
5	继电器	RELAY	PARTS NO.005	
6	滑块X	X SLIDER	PARTS NO.006	
7	滑块Y	Y SLIDER	PARTS NO.007	
8	关节轴承	KNUCKLE BEARING	PARTS NO.008	
9	皮带轮	PULLEY	PARTS NO.009	
10	皮带	BELT	PARTS NO.010	
11	电机	MOTOR	PARTS NO.011	
12	按钮开关	BOTTON SWTICH	PARTS NO.012	
13	轴承支座	BEARING WITH SUPPORT	PARTS NO.013	
14	脚踏开关	SWTICH	PARTS NO.014	
15	摆杆	ROD	PARTS NO.015	
16	刷头	BRUSH SUPPORT	PARTS NO.016	
17	刷子	BRUSH	PARTS NO.017	

